

Bicycle Service and Condition Checklist

Bike Make/Model _____

| | | Pass | Fail | Remarks |
|-------------------------|---|------|------|---------|
| Front tyre | good tread; no splits, cracks or holes; properly inflated; valve straight | | | |
| Front wheel | true; no broken/missing spokes; good rim | | | |
| Front hub | no wobble; turns smoothly; wheel securely fixed | | | |
| Front mudguard | firmly fixed; no sharp mudguard stays | | | |
| Front brake blocks | correctly fitted and aligned; not worn away | | | |
| Front brake | firmly fixed; correctly adjusted | | | |
| Front brake lever | comfortable position, firmly fixed, no excessive travel; cable not frayed | | | |
| Headset/steering | no wobble; correctly adjusted | | | |
| Handlebars | not distorted; ends protected | | | |
| Front forks | appear true and undamaged | | | |
| Frame | appears true and undamaged | | | |
| Rear brake lever | comfortable position; firmly fixed; no excessive travel; cable not frayed | | | |
| Rear brake | firmly fixed; correctly adjusted | | | |
| Rear brake blocks | correctly fitted and aligned; not worn away | | | |
| Rear mudguard | safely fixed; no sharp mudguard stays | | | |
| Rear tyre | good tread; no splits, cracks or holes; properly inflated; valve straight | | | |
| Rear wheel | true; no broken/missing spokes; good rim | | | |
| Rear hub | no wobble; turns smoothly; wheel securely fixed | | | |
| Bottom bracket | no wobble; turns smoothly; lock rings tight (if present); sufficiently lubricated | | | |
| Pedal cranks | straight; firmly fixed | | | |
| Pedals | complete; turning freely; not bent; firmly fixed | | | |
| Chainwheel | not bent; teeth not worn | | | |
| Chainguard | firmly fixed; not bent | | | |
| Chain | not too worn; not slack; not rusty; lubricated properly | | | |
| Gears | properly adjusted; lubricated sufficiently | | | |
| Saddle | firmly fixed; straight; comfortable height (unless BMX) | | | |
| Rack/carrier/bags etc | firmly secured | | | |
| Front lamp (if carried) | white; firmly fixed; good light to front; correct height | | | |
| Rear lamp (if carried) | red; firmly fixed; visible to rear; correct height | | | |
| Reflectors | clean and secure | | | |
| Cables | correctly adjusted; not frayed | | | |

Signature of tester _____

Date of test _____

Place of test _____



www.therapidwrench.com
0416 177 802